



## SKYSTAR USB HD

HDTV USB box for the reception of digital satellite on your notebook or PC

| EAN           | Colour | Item no.  | Weight (Box) | Weight | Device (W x H x D) | Box                 |
|---------------|--------|-----------|--------------|--------|--------------------|---------------------|
| 4019588410947 | black  | 4109/3734 | 500 g        | 100 g  | 2,5 x 10 x 10 cm   | 17 x 14,1 x 10,5 cm |
| 4019588410954 | black  | 4109/3735 | 500 g        | 100 g  | 2,5 x 10 x 10 cm   | 17 x 14,1 x 10,5 cm |

### CONNECTIONS

F socket: 1

### HDTV SYSTEM REQUIREMENTS

Processor: Intel Pentium 4 or AMD Athlon x2

Processor cyle time: 3 GHz

Graphics card: Current PCI-Express Graphics card  
with min. 256 MB of RAM

### OPERATING SYSTEM

Windows 7 32/64: Yes

Windows XP 32/64: Yes

Windows Vista 32/64: Yes

### SYSTEM REQUIREMENTS (MINIMUM REQUIREMENTS)

Processor: Intel P4

Processor cyle time: 1,8 GHz

Hard disc memory (programme): 64 MB

Hard disc memory (DVR): 10 GigaByte

Graphics card: 3D graphics card

Required connector: 1x USB 2.0

DirectX: 9 (oder höher)

### TUNER

TECHNIROUTER ready: Yes

### SCOPE OF DELIVERY

SkyStar USB HD, Remote control including  
batteries, USB cable, Mains unit, TE2 DVBViewer  
software, EVE v2 video editing software, NDIS and  
BDA drivers, Manuals  
(Quickinstall)<br><br><br><br>